

### Hybrid Foamatic Mainstation Service Check List

Location	Description	Action	6 months	12 Months	18 Months	24 Months
1	Inlet filter	Inspect and clean inlet filter	X	X	X	X
2	Flow switch	Inspect operation and adjust to 1 green light.	X	X	X	X
3	Sensors	Check condition of sensors and check display for supply pressure, pump top pressure and temp.	X	X	X	X
4	Air regulator	Adjust pressure to ensure manometer operates and adjust to correct pressure.	X	X	X	X
5	Air non return valve	Disassemble and Inspect/ Replace O-ring Replace complete NRV	X		X	
6	Chemical valve	Check operation and o-rings Replace complete chemical valve	X	X	X	
7	Pneumatic valves	Check valves open and close smoothly with air manual switch and electronically	X	X	X	X
8	Selector switch axel	Inspect O-rings/ Replace O-rings	X	X	X	X
9	Chemical Non return valve	Disassemble, inspect/ replace O-ring Replace complete NRV	X		X	
10	Chemical hoses	Replace chemical hoses		X		X
11	Restrictor nozzle	Inspect nozzle for blockages and/or damaged O-ring		X		X
12	Water Non return valve	Disassemble, inspect/ replace O-ring Replace complete NRV	X		X	
13	Injectors	Clean, Inspect/ Replace O-rings Replace	X		X	
14	Air non return valve	Check operation Replace complete NRV	X		X	
15	Air valve	Inspect operation/ clean and lubricate piston Replace if required	X		X	

